



## One-step UV Primer/Filler

### TSP 1500

- One component primer/filler; No mixing with other products necessary
- To be dried with UV lamp (UVL 00)
- 1-2 minutes drying (depending on the layer thickness)
- 1 step system
- Higher productivity: increased time efficiency, energy saving
- For use on sanded and clean steel, aluminum, galvanized steel, dried and sanded OEM finishes, polyester fillers, hard and semi-hard plastics, ...
- Ideal for spot & smart repair

Code	Description	Box	Pal
TSP 1500	One-step UV Primer/Filler 400ml	12	672

