



The new TSP 1500 dries much faster than its predecessor. Evaporation has also been greatly improved. This now takes only 20 seconds flash off (instead of 2 minutes). After drying, you can immediately sand. Cleaning afterwards is no longer necessary.



NEW

ONE-STEP UV PRIMER/FILLER

TSP 1500

One component primer/filler



ONE-STEP UV PRIMER/FILLER

TSP 1500

- One component primer/filler; No mixing with other products necessary
- To be dried with UV lamp (UVL 00)
- 1-2 minutes drying (depending on the layer thickness)
- 1 step system
- Higher productivity: increased time efficiency, energy saving
- For use on sanded and clean steel, aluminum, galvanized steel, dried and sanded OEM finishes, polyester fillers, hard and semi-hard plastics, ...
- Ideal for spot & smart repair



▶ WATCH
VIDEO

