



Premium pneumatic eccentric sanding machine

SAM 50-51

Spare part list:

no.	Code	Description
1		External retaining ring
2		Bearing
3		Rear endplate
4		Cylinder assembly
5		O-ring
6		Rotor
7		Woodruff key
8		Vane
9		Front endplate
10		Bearing
11		O-ring
12		Lock ring
13		Orbit AirSHIELD plustw shaft balancer
14		Filter
15		Duckbill check valve
16		Valve retainer
17		Double row angular contact bearing-1seal
18		Spacer 0.2 Thk
19		Belleville washer
20		retaining ring
21		Spindle
1-21	5080	2.5 mm (5353 3325)
1-21	5081	5.0 mm (5353 3350)
22a	5022A	throttle lever for 3/32-2,5mm
22b	5022B	throttle lever for 3/16-5mm
23	5023	Lever spring pin
24	5024C	3 in. grip

no.	Code	Description
25	5025	Valve sleeve
26	5026	Machined housing - Grey pms 422
27	5027	Valve stem assembly
28	5028	O-ring
29	5029	Speed control
30	5030	Internal retaining ring
31	5031	5/8 in. non-vacuum shroud
32	5032	5/8 in. Super vac shroud
33	5033	6 in. screen abrasive ros super vac shroud
34	5034	24mm pad wrench
35	5035	1 back-up pad supplied with each tool
36	5036	Internal muffler
37	5037	Muffler insert
38	5038	Muffler housing
39	5039	Valve seat
40	5040	Valve
41	5041	Valve spring
42	5042	Inlet bushing assembly
43	5043	O-ring
44	5044	SGV retainer
45	5045	Assembly for 1 in./28mm adapter coupling and airline assembly
46	5046	1 in./28mm hose seal
47	5047	Generic 1"/28mm hose super vac sgw swivel exhaust fitting
48	5048	Super vac sgw skirt/shroud adapter
51	5051	Ros supervactw cv 1 in./28mm swivel exhaust assembly
52	5052	Flanged nut
53	5053	Washer
54	5054	Screw
55	5055	Ros super vactw cv 3/4 in. swivel exhaust assembly