

Supplies :



SPRAY GUN KIT

SPG 500K



SPRAY GUN

SPG 500

1



1 Remove screw and spring

2



2 Install fluid nozzle



3 Install air cap



4 Loosen screw



5 Insert needle



6 Install spring



7 Install regulator knob



8

- Tighten screw until needle doesn't move
- Gently loosen the screw until the needle moves fluently again.